

**TCEQ Mechanical Sources
Current Maintenance, Startup, and Shutdown (MSS) Best Available Control Technology (BACT) Guidelines**

Bulk Material Handling

Source Type	Pollutant	Minimum Acceptable Control	Details
Material Handling	Particulate Matter (PM)	No downtime since [1] water sprays should be functioning with number and flow rate prior to the start of operation, [2] material should be wet, [3] enclosures should be in place, and [4] fabric filters should be in good repair with an acceptable pressure drop prior to the start of operation	
Material Transferring/Stockpiles		No downtime since water sprays at transfer points and on stockpiles should be functioning prior to the start of operation	