

TCEQ Mechanical Sources

Current Maintenance, Startup, and Shutdown (MSS) Best Available Control Technology (BACT) Guidelines

Metallizing/Metal Spraying Operations

Source Type	Pollutant	Minimum Acceptable Control	Details
Metallizing/Metal Spraying Operations	Particulate Matter (PM)	Best management practices employed during maintenance, no additional controls required for startup and shutdown operations beyond Current BACT Guidelines, no bypassing of controls	Best management typically achieved by conducting maintenance indoors and conducting housekeeping to minimize re-entrainment of settled PM